130*70mm

EST 1997
A4TECH

FG2200 Air

QUICK START GUIDE




FSTYLER COLLECTION

WHAT'S IN THE BOX



KNOW YOUR KEYBOARD



Flashing Red light indicates when the battery is below 25%.

THE FLANK / BOTTOM



SYSTEM SWAP



WINDOWS/MAC OS KEYBOARD LAYOUT

System	Shortcut [Long Press for 3S]	Indicator Light
Windows	fn + P win	m/w Flashing Off
Mac OS	fn + O mac	


Note: Windows is default system layout.
The device will remember the last keyboard layout, please switch as needed.

FN MULTIMEDIA KEY COMBINATION SWITCH

FN Mode: You can lock & unlock Fn mode by short pressing FN + ESC by turn.

① Lock Fn Mode: No need to press FN key
② Unlock Fn Mode: FN + ESC

※ After pairing, FN shortcut is locked in FN mode by default, and the locking FN is memorized when switching and shutting down.




DUAL-FUNCTION KEY

Multi-System Layout


Shortcuts	win (Windows)	mac (Mac OS)
fn + O win / P mac	**Switching Steps:** ① **Choose Mac layout by pressing Fn+O.** ② **Choose Windows layout by pressing Fn+P.**	
ctrl	Ctrl	Control ^
alt	Start	Option ⌥
alt	Alt	Command ⌘
alt	Alt (Right)	Command ⌘
ctrl	Ctrl (Right)	Option ⌥

KNOW YOUR MOUSE




[Desk + Air] DUAL FUNCTIONS

Just lift up the mouse in the air to turn it into a multimedia controller.



CONNECTING 2.4G DEVICE



①
①Plug the receiver into the computer's USB port.
②Use the Type-C adaptor to connect the receiver with the computer's Type-C port.

②
Turn the mouse & keyboard power switch on.

TECH SPEC

Sensor: Optical
Style: Symmetric
Report Rate: 125 Hz
Resolution: 1200 DPI
Buttons No.: 3
Size: 108 x 64 x 35 mm
Weight: 85 g (w/ battery)

Keycap: Chocolate Style
Keyboard Layout: Win / Mac
Character: Laser Engraving
Report Rate: 125 Hz
Size: 313 x 138 × 26 mm
Weight: 344 g (w/ battery)

Connection: 2.4G Hz
Operation Range: 10~15 m
System: Windows 7/8/8.1/10/11

Q & A

Question Can the keyboard support Mac platforms?

Answer Support: Windows | Mac keyboard layout switching.

Question Does the layout can be remembered?

Answer The layout you used last time will be remembered.

Question Why can't the function lights in Mac system prompt?

Answer Because Mac system does not have this function.

WARNING STATEMENT

The following actions may damage the product.

1. To disassemble, bump, crush, or throw into fire is forbidden for the battery.
2. Do not expose under the strong sunlight or high temperature.
3. The discard of battery should obey to the local law, if possible please recycle it. Do not dispose it as household garbage, because it may cause an explosion.
4. Do not continue to use if severe swelling occurs.
5. Please do not charge the battery.

EST 1997
A4TECH | FSTYLER COLLECTION

www.a4tech.com

Scan for E-Manual