EST. 1987
A4TECH®

FSTYLER
COLLECTION


FSTYLER LOW PROFILE SCISSOR SWITCH KEYBOARD

QUICK START GUIDE

FX50

www.a4tech.com

Package Including




Keyboard



User Manual

Product Features



❶ FN Locking Mode

❷ 12 Multimedia & Internet Hotkeys

❸ Caps Lock Indicator

❹ Win / Mac Dual-Function Keys

❺ Win / Mac Switch & Scroll Lock Indicator

❻ Calculator / Start Music

❼ Win / Mac Keyboard Layout Switch

❽ Num Lock Indicator

Windows/Mac OS Keyboard Layout

System	Shortcut [Long-Press for 3S]	Indicator Light
Windows	win	scroll lock Scroll Lock Flashing Off
Mac OS	mac	

Note: Windows is default system layout.
The device will remember the last keyboard layout, please switch as needed.

FN Multimedia Key Combination Switch

esc

FN Lock Mode: To select the Multimedia features as your main command, lock the FN mode by pressing FN+ESC. To unlock, press FN+ESC again.

F1	F2	F3	F4	F5	F6
Home Page	System Switching	Backward	Search	Input Switching	Screen Capture

F7	F8	F9	F10	F11	F12
Previous Track	Play / Pause	Next Track	Mute	Volume Down	Volume Up

Other FN Shortcuts Switch

Shortcuts	Windows	Mac OS
fn + enter	Screen Lock	Not Support
fn + ▲	Brightness +	
fn + ▼	Brightness -	

Note: The final function refer to the actual system.

Dual-Function Key

Shortcuts	Windows	Mac OS
mac / win	**Switching Steps:** **① Choose Windows layout by pressing win.** **② Choose Mac OS layout by pressing mac.**	
ctrl ^	Ctrl	Control ^
opt ⌥	Start ⊞	Option ⌥
alt / cmd ⌘	Alt	Command ⌘
alt / cmd ⌘	Alt (Right)	Command ⌘
ctrl / opt ⌥	Ctrl (Right)	Option ⌥

Product Specifications

Model: FX50

Switch: Scissor Switch

Actuation Point: 1.8 ± 0.3 mm

Keycaps: Chocolate Style

Character: Silk Printing + UV

Keyboard Layout: Win / Mac

Hotkeys: FN + F1 ~ F12

Report Rate: 125 Hz

Cable Length: 150 cm

Port: USB

Includes: Keyboard, User Manual

System Platform: Windows / Mac

Q & A

Question **Can the keyboard support Mac platforms?**

Answer Support: Windows | Mac keyboard layout switching.

Question **Does the layout can be remembered?**

Answer The layout you used last time will be remembered.

Question **Why does the function light not indicate in Mac OS System?**

Answer Because the Mac OS system does not have this function.

EST. 1987
A4TECH®

FSTYLER
COLLECTION

www.a4tech.com

Scan for E-Manual